

Aerator Dual Thread Sink Spray Spout

INSTALLATION INSTRUCTIONS

⚠ CAUTION: DO NOT INSTALL THIS PRODUCT UNTIL YOU READ AND UNDERSTAND ALL INSTRUCTIONS. FAILURE TO FOLLOW THESE INSTRUCTIONS MAY RESULT IN PERSONAL INJURY, PROPERTY DAMAGE OR PRODUCT FAILURE.

For use with 15/16 in male, 55/64 in female or dual thread aerators

1. Unthread aerator from faucet and remove washer and insert.
2. Place new insert and appropriate washer into aerator body.
3. Thread aerator onto faucet spout threads by hand.

No Tools Needed for Installation.

AIREADOR DE MEZCLADORA

INSTRUCCIONES DE INSTALACIÓN

⚠ PRECAUCIÓN: NO INSTALE ESTE PRODUCTO HASTA QUE LEA Y COMPRENDA TODAS LAS INSTRUCCIONES. EL INCUMPLIMIENTO DE ESTAS INSTRUCCIONES PUEDE OCASIONAR LESIONES PERSONALES, DAÑOS A LA PROPIEDAD O FALLAS DEL PRODUCTO.

1. Descosa el aerador del grifo y quite la lavadora e insértela.
2. Coloque el nuevo separador de millares y la lavadora apropiada (para 15/16 varón o aeradores de 55/64 cuerda de rosca femenina) en cuerpo del aerador.
3. El aerador de la cuerda de rosca sobre.

No Herramientas Necesarias.



Brasscraft Manufacturing Co., 39600 Orchard Hill Place Novi, Michigan 48375-5331
TOLL-FREE: 877.272.7755 FAX: 248.305.6011 www.brasscraft.com

Manufacturer assumes no responsibility for failure due to improper installation.

©2019 Brasscraft Manufacturing Company, Novi, MI 48375-5331 U.S.A.

All Rights Reserved. www.brasscraft.com BrassCraft® brand is a trademark of Brasscraft Mfg. Co.
El fabricante no asume ninguna responsabilidad si la instalación no se hace de acuerdo al instructivo.
BrassCraft® brand es una marca registrada de Brasscraft Mfg. Co.