

**Read All Instructions Carefully Before Installing**  
(Lea cuidadosamente las instrucciones antes de instalar)

## **30% Water Savings - 1.5 GPM Low Flow vs. Standard 2.2 GPM Aerator**

For use with 15/16" male, 55/64" female or dual thread aerators

(Read All Instructions Carefully Before Installing)

1. Unthread aerator from faucet and remove washer and insert.
2. Place new insert and appropriate washer into aerator body.
3. Thread aerator onto faucet spout threads by hand.

**No Tools Needed for Installation.**

## **AIREADOR DE MEZCLADORA**

Contenido: 3 Piezas

(Lea cuidadosamente las instrucciones antes de instalar)

1. Descosa el aerador del grifo y quite la lavadora e insértela.
2. Coloque el nuevo separador de millares y la lavadora apropiada (para 15/16 varón o aeradores de 55/64 cuerda de rosca femenina) en cuerpo del aerador.
3. El aerador de la cuerda de rosca sobre

**No Herramientas Necesarias.**

**BrassCraft®**

**SERVICE PARTS**

**BrassCraft Manufacturing Co.**

39600 Orchard Hill Place

Novi, Michigan 48375-5331

TOLL-FREE: (866) 625-2007

FAX: (248) 374-3716

[www.brasscraftserviceparts.com](http://www.brasscraftserviceparts.com)