

Tub Spout Universal Fit

INSTALLATION INSTRUCTIONS

⚠ CAUTION: DO NOT INSTALL THIS PRODUCT UNTIL YOU READ AND UNDERSTAND ALL INSTRUCTIONS. FAILURE TO FOLLOW THESE INSTRUCTIONS MAY RESULT IN PERSONAL INJURY, PROPERTY DAMAGE OR PRODUCT FAILURE.

For 1/2 in Copper Pipe Unthreaded Connections

1. Unthread present tub spout.
2. Check length of copper tube. Tube should be no longer than 1 in. from the wall. If longer than 1 in., cut end of copper tube evenly and remove all burrs.
3. Slide brass adapter onto copper tubing and tighten set screw with allen wrench provided.
4. Thread extension nipple onto brass adapter, hand tighten.
5. Wrap extension nipple with pipe thread tape three times around.
6. Thread tub spout onto extension tube, hand tighten.

Parts Needed for Installation:

- Brass adapter
- Extension nipple
- Tub spout

Tools Needed for Installation:

- Pipe thread tape
- Allen wrench

For 1/2 in. Threaded Male Pipe Connections

1. Unthread present tub spout.
2. Wrap threaded end of wall pipe with pipe thread tape three times around.
3. Thread tub spout onto threaded wall pipe, hand tighten.

Parts Needed for Installation:

- Pipe thread tape

Tools Needed for Installation:

- Pipe thread tape

FOR 1/2 IN THREADED CONNECTIONS

1. Unthread present tub spout.
2. Wrap threaded end of wall pipe with pipe thread tape three times around.
3. Thread tub spout onto threaded wall pipe, hand tighten.

Parts Needed for Installation:

- Tub spout

Tools Needed for Installation:

- Pipe thread tape

For 1/2 in. Threaded Male Pipe Connections

1. Unthread present tub spout.
2. Wrap threaded wall tubing with pipe thread tape three times around.
3. Thread plastic reducing adapter onto threaded wall tubing, hand tighten.
4. Wrap reducing adapter with pipe thread tape three times around.
5. Thread extension nipple onto reducing adapter. Ensure extension nipple is flush with back of reducing adapter.
6. Wrap extension nipple with pipe thread tape three times around.
7. Thread tub spout onto extension tube, hand tighten.

Parts Needed for Installation:

- Extension nipple
- Plastic reducing adapter
- Tub spout

Tools Needed for Installation:

- Pipe thread tape

For 3/4 in. Threaded Male Connections

1. Unthread present tub spout.
2. Wrap threaded end of wall pipe with pipe thread tape three times around.
3. Thread extension nipple onto threaded end of wall pipe.
4. Wrap extension nipple with pipe thread tape three times around.
5. Thread tub spout onto extension tube, hand tighten.

Parts Needed for Installation:

- Extension nipple
- Tub spout

Tools Needed for Installation:

- Pipe thread tape